

# Elphie's Choice

SKU 3590




Looking for a WICKED good time? Reach for this gorgeous green vibe and cast a satisfying spell with Elphie's Choice! The curved silky, silicone shaft provides a strong double tapping sensation to massage the G-spot or P-spot. Simultaneously, the soft, tantalizing tongue laps externally in a dizzying array of rhythms and speeds. Separate or synchronized, the high quality motors bring you ten super-powered licking and/or tapping options. What is this feeling? It's an intense climax! No wonder this wonderful vibe is so popular!

## Features:

- 5 year warranty
- Silicone & ABS
- Phthalate free
- Total length: 9 inches
- Width: 1.63 inches
- Insertable Length: 5 inches
- Insertable Diameter: 1.48 inches
- Rechargeable – Magnetic USB cable included

## \*Splashproof (IPX6):

(IPX6) - Not submersible. Water projected in powerful jets against an enclosure from any direction has no harmful effects and complete protection against contact with dust.



## Cleaning

Always clean product before and after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-2762).

## Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). Not for use with silicone lubricants. You can find additional lubrication options on our web site or in our online catalog.

**To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:**

Do not store products near extreme cold or heat. Store in a cool, dry location. Store products separately as different materials may react with each other. Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

**Caution: For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.**

## Warranty

All sales are final due to the intimate nature of our products. *Elphie's Choice* is guaranteed for a replacement for 5 years for the exact same item. No cash refunds will be given. Please reference our digital catalog or website shopping cart for individual extended product warranties for many of our motorized items. Athena's warranty covers the pleasure device only. No incidental or consequential damages resulting from the use of this product are warrantied. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. The warranty gives specific legal rights and you may have other legal rights which vary from state to state.

If you receive a broken product or if your product breaks within its specific warranty, please contact your Goddess or Adonis if purchased at a party, or our Customer Care Liaison if purchased on our website, for instructions on how to send back your item for a replacement if required. Our Customer Care Liaison can be reached by calling (877) ATHENAS or Email to: [customerservice@athenashn.com](mailto:customerservice@athenashn.com) All defective product returns must be accompanied by a pre-authorization number. If product arrives broken or breaks within 60 days, it's the client's responsibility to pay for the shipping of the broken item to Athena's if required. Athena's is responsible for the shipping of the replacement. If this item breaks after 60 days of receipt, it's the client's responsibility to pay for the shipping of the broken item to Athena's if required and the shipping for the replacement item.

©May 2025  
Athena's Home Novelties, Inc.  
[www.athenashn.com](http://www.athenashn.com)  
1-877-ATHENAS

For Warranty Information and Motorized  
Pleasure Device Best Practices please scan here.




## Charging

Connect the USB plug into a power source at one end and the magnetic charger onto the pins located at the back of the toy's base. The indicator light will flash while device is charging and stay constant when toy is fully charged.

It is recommended not to overcharge for extended periods of time. Remove cord prior to operating.

Charge Time: 60-80 minutes

Run Time: 50-70 minutes



## Operating

**The control panel is located at the front of the toy's handle. There are two motors controlled separately.**

**ON:** Press the bottom power button for 1.5 seconds to turn toy ON. The button will light up and both motors will begin in standby.

**FLICKING:** Press the bottom button again to engage flicking in the external tongue. Press again to cycle through 10 tongue speeds and rhythms.

**TAPPING:** Once the toy is in standby, press the top button to engage the tapping motor at the head of the main shaft. Press again to cycle through 10 tapping speeds and rhythms. Hold down for 1.5 seconds to return to standby.

**OFF:** Press and hold the bottom power button for 1.5 seconds. The lights will turn off and both motors will cease.

