



Fancy That

SKU 3597

Could it be a lipstick? A luxe mini perfume bottle? Hmm... Remove the cap and you'll uncover a chic little secret! Surprise! It's a mini-vibe with a discreet vibrating tip — perfect for pin point intensity whether you are solo or playing with your partner. *Fancy That* comes with 3 interchangeable silicone attachments — a split tip, a flower and round bead. With 10 functions you can tap, tease or tantalize in and out of the bath or shower! Whether tucked away in a nightstand or carried in a handbag, the discreet and versatile variety will be there to suit your vibe!

Features:

- 10 Vibration Speeds and Patterns
- Waterproof
- Silicone & ABS
- Phthalate & Latex Free
- Total Length: 3.5 inches
- Width: 1 inch
- Rechargeable – USB cable included



Cleaning

Always clean product before and after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-2762).

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). Not for use with silicone lubricants. You can find additional lubrication options on our web site or in our online catalog.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat. Store in a cool, dry location. Store products separately as different materials may react with each other. Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

Caution: For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty

All sales are final due to the intimate nature of our products. *Fancy That* is guaranteed for a replacement for 1 year for the exact same item.

For Warranty Information and Motorized Pleasure Device Best Practices please scan here.



©September 2025
Athena's Home Novelties, Inc.
www.athenashn.com
1-877-ATHENAS

Charging


This toy arrives with a partial charge. It is recommended to charge this toy before use.

To charge, connect the USB plug into the power source and insert the pin into the hole marked DC at the bottom of the toy.

The indicator light in the power button will flash while the device is charging and glow solid when the toy is fully charged.

Initial Charge: 80 minutes

Run Time: 60 minutes



Operating

Remove the cap before operating. Locate the power button in the center of the bottom half of the toy.

ON: Press and hold the power button for 2 seconds. The button will light up and the toy will be in standby mode.

VIBRATION SPEEDS & PATTERNS: Press the button again to cycle through 10 vibration speeds and patterns.

OFF: Press and hold the power button for 2 seconds. Light will turn off and vibration will cease.

ATTACHMENTS: While the toy is off, align the tip with the hole at the bottom of the attachment. Gently press the tip into the hole. Turn *Fancy That* on and begin stroking your erogenous zone of choice!

