



Rhapsody in Blue

SKU 3598


Your symphony of sensation is just beginning as you slip your finger through the gleaming chrome loop handle of this breathtaking baby-blue dual stimulator. The arched, flexible shaft with its textured, tapered head seeks contact with the G-spot for deep, resonant thrills. The double-tongue clitoral stimulator massages and vibrates, building to a crescendo. With two independent motors and 7 vibration rhythms, you control the tempo of your pleasure, from a slow tease to a rapturous finale. The luxurious design crafted from body-safe silicone is pleasure orchestrated to perfection.

Features:

- 7 Vibration Speeds and Patterns
- Rechargeable – Magnetic USB cable included
- Splashproof (IPX5)*
- Silicone & ABS
- Phthalate & Latex Free
- Total Length: 8.5 inches
- Insertable Length: 5 inches
- Insertable diameter: 1.43 inches

*Splashproof (IPX5):

(IPX5) - Protected against low pressure water stream from any angle.



Cleaning

Always clean product before and after every use. For best results we recommend using Athena's (anti-microbial) Mighty Tidy Toy Cleaner (SKU MTT-2762).

Lubrication

Be sure to use ample lubrication with your bedroom toys. For great results try Athena's Perfectly Pure Intimate Moisturizer (SKU 5701). Not for use with silicone lubricants. You can find additional lubrication options on our web site or in our online catalog.

To ensure that you always enjoy a pleasurable experience with your adult novelty items, follow the care instructions listed below:

Do not store products near extreme cold or heat. Store in a cool, dry location. Store products separately as different materials may react with each other. Take caution when placing lotion and massage oil bottles or adult novelties directly on furniture surfaces. Place them on a cloth to protect your toys and your furniture.

Caution: For adult use as a non-medical pleasure device only. Discontinue use in the event of any medical condition or pain.

Warranty

All sales are final due to the intimate nature of our products. *Rhapsody in Blue* is guaranteed for a replacement for 5 years for the exact same item.

For Warranty Information and Motorized Pleasure Device Best Practices please scan here.




©September 2025
Athena's Home Novelties, Inc.
www.athenashn.com
1-877-ATHENAS

Charging

This toy arrives with a partial charge. It is recommended to charge this toy before use.

To charge, connect the USB plug into the power source and align the magnetic pins to the two dots on the bottom of the backside of the toy.

The indicator light in the power button will flash while the device is charging and glow solid when the toy is fully charged.



Operating

Locate the control panel on the bottom of the front of the toy.

ON: Press and hold down the power button for 2 seconds. The power button will light up and the toy will be in standby mode.

SHAFT VIBRATION SPEEDS & PATTERNS: Press the power button again to cycle through 7 vibration speeds and patterns in the shaft. To turn the shaft vibration off, press and hold the power button for three seconds. Light will turn off and vibration will cease.

EXTERNAL DOUBLE TONGUES: Press and hold the button with the vibration wave icon to cycle through the 7 vibrating speeds and functions of the tongues. To deactivate the tongues only, press and hold and hold the vibration wave icon button for 2 seconds.

OFF: Press and hold the power button for 2 seconds. Light will turn off and vibration will cease.

Double Tongues Vibrations

On/Shaft Vibrations/Off

